



# INSTALLATION INSTRUCTIONS

## Part Number 85-9000

**This bracket fits:** SEE CATALOG FOR CURRENT APPLICATIONS

High performance riding puts a lot of stress on the intake manifold. Use this bracket with K&N Adapter part number 85-9294 to stabilize the carburetors.

**NOTE:** Put Loctite on all fasteners and periodically check for cracks or looseness.

